

機種名	キャリア型番			TypeC
	docomo	au	SoftBank	変換アダプタ
				AE-217 AE-218
Apple				
iPhone Air	A3516 (日本)			×
iPhone 17 Pro Max	A3525 (日本)			×
iPhone 17 Pro	A3522 (日本)			×
iPhone 17	A3519 (日本)			×
iPhone 16e	A3409 (日本)			×
iPhone 16 Pro Max	A3295 (日本)			×
iPhone 16 Pro	A3292 (日本)			×
iPhone 16 Plus	A3289 (日本)			×
iPhone 16	A3286 (日本)			×
iPhone 15 Pro Max	A3105 (日本)			×
iPhone 15 Pro	A3101 (日本)			×
iPhone 15 Plus	A3093 (日本)			×
iPhone 15	A3089 (日本)			×
iPhone 14 Pro Max	A2893 (日本)			×
iPhone SE (第3世代)	A2782 (日本)			×
iPhone 13 Pro	A2642 (日本)			×
iPhone 13 mini	A2626 (日本)			×
iPhone 12 Pro Max	A2410 (日本)			×
iPhone 12 mini	A2398 (日本)			×
iPhone 12	A2402 (日本)			×
iPhone SE (第2世代)	A2296			×
iPhone 11Pro Max	A2215			×
iPhone 11Pro	A2218			×
iPhone 11	A2221			×
iPhone XR	A1984、A2105、A2106 (日本)			×
iPhone Xs Max	A1921、A2101、A2102 (日本)			×
iPhone Xs	A1920、A2097、A2098 (日本)			×
iPhone X	A1865、A1901、A1902			×
Sony				
Xperia 10VI	SO-52E	SOG11	A402SO	×
Xperia 10IV	SO-52C	SOG07	A202SO	×
Xperia 5 III	SO-53B	SOG05	A103SO	×
Xperia 10III	SO-52B	SOG04	—	×
Xperia Ace II	SO-41B	—	—	×
Xperia 5 II	SO-52A	SOG02	A002SO	×
Xperia 10 II	SO-41A	SOV43		×
Xperia 1 II	SO-51A	SOG01		×
Xperia 5	SO-01M	SOV41	901SO	×
Xperia 8		SOV42		×
Xperia 1	SO-03L	SOV40	802SO	×
Xperia Ace	SO-02L			×
SAMSUNG				
Galaxy S25	SC-51F	SCG31	SM-S931Z	×
Galaxy A53 5G	SC-53C	SCG15	—	×
Galaxy S22	SC-51C	SCG13	—	×
Galaxy A22 5G	SC-56B	—	—	×
Galaxy S21 5G	SC-51B	SCG09	—	×
Galaxy S21 Ultra 5G	SC-52B	—	—	×
Galaxy A51 5G	SC-54A	SCG07	—	×
Galaxy Note 20 Ultra 5G	SC-53A	SCG06	—	×
Galaxy A21 (A21シンプル)	SC-42A	SCV49	—	×
Galaxy A41	SC-41A	SCV48	—	×
Galaxy S20+ 5G	SC-52A	SCG02	—	×
Galaxy S20 5G	SC-51A	SCG01	—	×
Galaxy A20	SC-02M	SCV46	—	×
Galaxy Note 10 +	SC-01M	SCV45	—	×
Galaxy A30		SCV43	—	×
Galaxy S10 +	SC-04L	SCV42	—	×
Galaxy S10	SC-03L	SCV41	—	×
SHARP				
BASIOactive	—	SHG09	—	×
AQUOS wish2	SH-51C	SHG08	—	×
シンプルスマホ 6	—	—	A201SH	×
AQUOS sense6s	—	SHG07	—	×
AQUOS sense6	SH-54B	SHG05	—	×
AQUOS sense 5G	SH-53A	SHG03	A004SH	×
AQUOS zero 5G basic	—	—	A002SH	×
AQUOS zero 5G basic DX	—	SHG02	—	×
AQUOS sense 3 basic	—	SHV48	—	×
AQUOS R5G	SH-51A	SHG01	908SH	×
AQUOS zero 2	SH-01M	SHV47	906SH	×
AQUOS sense 3 plusサウンド	—	SHV46	—	×
AQUOS sense 3	SH-02M	SHV45	—	×
かんたん携帯10	—	—	807SH	×
AQUOS R3	SH-04L	SHV44	808SH	×
AQUOSケ-タイ	SH-02L	—	—	×
AQUOS R2 compact	—	—	803SH	×
京セラ				
かんたんケータイライト	—	KYF43	—	○
TORQUE 5G	—	KYG01	—	○
かんたんケータイ	—	KYF41	—	○
GRATINA	—	KYV48	—	×
DIGNO ケータイ3	—	—	NP902KC	○
BASIO4	—	KYV47	—	×
TORQUE G04	—	KYV46	—	×
GRATINA	—	KYF39	—	×
URBANO V04	—	KYV45	—	×
FUJITSU				
arrows ケータイベーシック	F-41C	—	—	○
arrows 5G	F-51A	—	—	○
arrows Be4 plus	F-41B	—	—	×
らくらくスマートフォン	F-42A	—	—	×
arrows Be4	F-41A	—	—	×
らくらくホン	F-01M	—	—	×
arrows ケータイ	F-03L	—	—	×
arrows U	—	—	801FJ	×
arrows Be3	F-02L	—	—	×
らくらくスマートフォンme	F-01L	—	—	×
LG電子				
style3	L-41A	—	—	×
style2	L-01L	—	—	×
K50	—	—	802LG	×
HUAWEI				
P30 Pro	HW-02L	—	—	×
P30 lite Premium	—	HWV33	—	×
Mate 20 Pro	—	—	LYA-L09	×
Google				
Pixel 8a	—	Pixel 8a	Pixel 8a	×
Pixel 6a	—	Pixel 6a	Pixel 6a	×
Pixel 6	—	Pixel 6	Pixel 6	×
Pixel 5	—	Pixel 5	Pixel 5	×
Pixel 4a(5G)	—	—	Pixel 4a	×
Pixel 4 XL	—	—	Pixel 4 XL	×
Pixel 4	—	—	Pixel 4	×
Pixel 3a XL	—	—	Pixel 3a XL	×
Pixel 3a	Pixel 3a	—	Pixel 3a	×
OPPO				
Reno11 A	—	—	A401OP	×
Reno7 A	—	OPG04	—	×
A54 5G	—	OPG02	—	×
Reno3 5G	—	—	A001OP	○
Find X2 Pro	—	OPG01	—	○
Xiaomi				
Redmi Note 9T	—	—	A001XM	×
Mi 10 Lite 5G	—	XIG01	—	×
ZTE				
ZTE a1	—	ZTG01	—	×
Axon 10 Pro 5G	—	—	902ZT	×

携帯電話機本体に発信機能がない端末では、スイッチは使用できません。受信・通話終了はスイッチボタンで操作ができます。

注意 イヤホンを使用時以外は取り外して下さい。

●発信についてはオート発信、自動発信と呼ばれる携帯電話本体の機能となります。

予め携帯電話に登録したメモリー番号に発信します。したがって、発信箇所は通常1件となります。

●一部の機種に番号表示させて発信する機種もありますが、本体を操作しないで発信する件数は1件とご理解ください。